

Rigging Guidelines

In an effort to ensure the safety of the guests, exhibitors, contractors and employees of Seattle Convention Center (SCC), we have implemented a rigging installation and certification policy. Facility clients and their contractors must request advance approval for any rigging installations. Rigging diagrams must include location of hang points, all fixtures, and load calculations. Diagrams/drawings must be submitted to and approved by LMG, the in-house audio visual service partner at SCC, for 6ABC & 6E Ballroom rigging locations. All other areas must be submitted to your SCC Event Manager (EM) before installation of any rigging begins. All rigging requests must comply with the guidelines as outlined in this document.

Definitions

"Aerial Rigging": the attachment of objects to the ceiling grid steel, catwalk, air wall tracks, ballroom points or the suspension of objects from any portion of the physical building.

"Ground Supported Rigging": the attachment of objects to a load-bearing apparatus such as crank-up, electric, hydraulic, mechanized, self-climbing, manually built self-supporting truss systems, hoisting towers, single mast sound, lighting trees or other similar "stick" rigging device.

Hang Point Requirements and Load Limits for Aerial Rigging

Your EM or LMG can provide detailed facility rigging diagrams in .dwg or .pdf. All rigging installations must comply with the guidelines as outlined in this document and use approved rated and stamped hardware. Suspension points do not include light fixtures, sprinkler heads, conduit, HVAC ducts, or any other facility fixtures not specified below. Rigging/staging which obstructs service access or fire exits is not allowed. SCC will charge the rigging contractor or facility client for any costs associated with damage caused by faulty, unapproved or incorrect rigging installations. Any rigging that is not approved in advance may be subject to immediate removal at the expense of the facility client or their contractor. Any requested variance from these limits and requirements must be submitted to the EM at least 30 days in advance for review by the Director of Operations.

Ballrooms 6ABCE (Level 6):

- LMG is the exclusive provider of ballroom aerial rigging services. This includes labor, chain motor rental, span sets
 required to attach client truss systems to LMG chain motors, operable track hangers and rigging hardware required
 for the attachment of lighting, projection, sound or decorative elements to the fixed ceiling rigging grid.
- All qualified audio visual contractors may assemble truss systems as well as attach lighting, sound and projection equipment to truss system.
- An LMG technician is required to control (raise or lower) chain motors at all times.
- All qualified audio visual contractors may assemble and construct ground supported systems in the Ballroom spaces.
- Heavy Load Points: Load limit is 1,000 lbs. per point. No bridling allowed.
- Operable wall tracks: Load limit is 100 lbs. per hanger. Minimum distance between points is four feet.
- Soffits: Load limit is 40 lbs. per hanger.
- Rigging is not allowed from any other facility element not listed above.



Rigging Guidelines

Exhibit Halls 4ABC:

- Rigging in Exhibit Halls 4ABC requires that all hang-points have a 360 degree wrap of protection around the fireproofed structural trusses, and are clear of all sprinkler heads, wireless access points, and lighting structures.
- Beams: Load limit from bottom chord truss is 1,600 lbs. per point. Minimum distance between points is four feet. Hanging from bottom chord truss may bridle at no more than 45 degrees.
- Purlines (spreaders between beams): Hanging from purlines must be a dead hang (vertical) only. Load limit from purlines is 200 lbs. per point. Minimum distance between points is four feet.
- Catwalk: Hanging from catwalks must be a dead hang only. Load limit from catwalks is 200 lbs. per hanger. Minimum distance between hangers is 25 feet. Maximum of three hangers per 100 feet.
- Airwall Tracks: Hanging from an airwall track must be a dead hang only. Load limit from airwall tracks is 200 lbs. per point. Minimum distance between points is four feet.
- Rigging is not allowed from any fixtures not listed above.
- Rigging is not allowed from the high steel without prior approval.
- Rigging is not allowed from vertical cross members between top and bottom chord truss.
- Beam insulation may not be removed. Damage to insulation will be billed at \$125 per point to the client or contractor.

Exhibit Hall 4D (Skybridge):

- The structural tubes are the only elements available for any significant rigging loads. All installations must have a protective wrap of carpet around the structural tube(s) to shield it from the rigging gear.
- Structural tubing: Load limit is 2,500 lbs. per point. Minimum distance between points is 30 feet. Maximum weight per truss line is 7,500 lbs.
- Lighting cables: Minimal hanging of banners or other lightweight décor may be allowed with specific advance approval of the EM. Load limit is 25 lbs. per item. Maximum of three items per light cable.
- Rigging is not allowed that will obstruct the HVAC vents.
- Movement of permanently installed theatrical lighting units is not permitted.

Exhibit Halls 4EF:

- Rigging in Exhibit Halls 4EF requires that all hang-points have a 360 degree wrap of protection around the structural trusses, and are clear of all sprinkler heads, wireless access points and lighting structures.
- Use of the rigging access panels at the entrance to Hall 4E will incur a usage fee.
- Main truss (runs north/south): Load limit is 2,500 lbs. per point. Minimum distance between points is 30 feet. Maximum weight per truss line is 20,000 lbs. Rigging is only allowed from the bottom chord of the truss line.
- Truss bracing (runs east/west): Load limit is 2,500 lbs. per point. Minimum distance between points is 30 feet. Maximum weight per brace line is 20,000 lbs. Rigging is only allowed from the bottom chord of the truss line.
- Catwalk: Hanging from catwalks must be a dead hang only. Load limit from catwalks is 200 lbs. per hanger. Minimum distance between hangers is 25 feet. Maximum of three hangers per 100 feet.
- Airwall tracks: Hanging from an airwall track must be a dead hang only. Load limit from airwall tracks is 200 lbs. per point. Minimum distance between points is four feet. Rigging from airwall tracks shall be with approved hangers only.
- Rigging is not allowed from vertical steel or diagonal bracing.
- Rigging is not allowed from the high steel without prior approval.
- Rigging is not allowed that exceeds a total of 2,500 lbs. on a truss and adjacent brace. Loads must be a full section apart.



Rigging Guidelines

Lobbies and Public Areas:

- Banners may be suspended above escalators from the glass handrails, provided they are affixed at the base of the handrail and allow for a minimum clearance of nine feet above the escalators.
- Permanently installed rails with adjustable hanging loops are provided on the north Levels 2, 3, and 4 for installation of banners.
- Eye bolts are installed on the Grand Escalator wall in the Atrium Lobby for banner placement.
- No rigging is allowed on Level 1
- No commercial or sponsorship signage or banners are allowed in lobbies or public areas without advance approval of the EM. Signage fees may apply.

Meeting Rooms and Hallways:

There are no weight bearing points in meeting rooms or hallways.

800 Pike Street:

- Tahoma Level: There are 150 permanently installed rigging points located throughout the floor. These points are provided by eyebolts installed every 15 feet on the steel beams. Maximum weight is 1,000 lbs. per point. There is no limit on how many points may be used simultaneously.
- Skagit, Chelan, Yakima Levels: There are no weight bearing points in meeting rooms or hallways on these levels.
- LMG must provide and install airwall track hangers. Maximum weight is 100 lbs. per hanger.
- Rigging is not allowed from steel beams.

Requirements for Ground Supported Rigging

- Free-standing items may not obstruct exit aisles, doorways, exit lights, AED devices, fire alarm pull boxes, fire hose cabinets, fire extinguishers, or service access.
- Support legs must be positioned, marked or otherwise protected to avoid trip hazards.
- Certified riggers may be required for ground supported rigging.

Installations Requiring a Certified Rigger

The information below is provided as a summary of common objects and apparatus that SCC requires a certified rigger to install. Each event may have special needs that cannot be addressed specifically in this document. Please consult your EM if you have questions.

Aerial Rigging:

Signage & Banners:

- Individual vinyl / foam core signs or banners (over 100 lbs.)
- Ceiling-hung rigid framed signs or displays (over 100 lbs.)
- Bridle or side load signage rigging (all weights)
- Ceiling-hung motorized/rotating signs (all weights)
- Chain hoists or powered devices used to hang signage (all weights)
- Air wall (operable wall) track hangers and all attached components (all weights)
- Any signage secured by means of beam clamp (all weights)



Rigging Guidelines

Lights, Sound, Projection, Props, Equipment, & Drapery:

- Bridle or side-load rigging (all weights)
- Ceiling-hung props or decorations (over 10 lbs.)
- Ceiling-hung truss hoist, sling, choker, cable, basket, span set, and beam clamp point connections or other rigging hardware attached to building or truss. (all weights)
- Catwalk-hung lighting, sound, projection, props secured by means of built-in clamp (over 10 lbs.)
- Operable wall track hangers and all attached components (all weights)
- Attachment of all objects to truss by means of cable, sling, span set, wire, rope, shackle or other non-clamping device (over 10 lbs.)
- Items secured to truss (while on ground), by means of clamp (over 25 lbs.)
- Soft goods hardware with live loads, such as pulleys and traveler tracks (all weights)
- Any object that requires the use of a ladder or lift to attach to a truss, rigging bar or other apparatus after it has been flown (all weights).

Ground Supported Rigging:

- Lighting, sound, projection or other equipment hung with a trimmed height greater than 12 feet, that are attached to a load-bearing apparatus by means of cable, sling, span set, wire, rope, shackle or other non-clamping device (over 10 lbs.)
- Items secured to truss (while on ground), by means of clamp (over 25 lbs.)
- Items attached to ground supported system that require the use of a lift or ladder (all weights)
- All ground supported installations with a trim height greater than 12 feet must be inspected and approved by a certified rigger, even if no individual component exceeds the weights limits described above.
- SCC does not require the use of certified riggers for the on-ground movement or assembly of equipment associated with rigging installations, such as truss, signage framing or props.

Certified Rigger Requirements

The Entertainment Technician Certification Program (ETCP) is an industry-wide program created by the Entertainment Services and Technology Association (ESTA). ETCP certification focuses on installation activities that directly affect the health and safety of crews, performers, and audiences and requires compliance with OSHA and other laws. ETCP certified riggers have met experience and training eligibility requirements and passed rigorous testing to ensure proper installation of rigging to temporarily suspend objects from overhead structures in any environment. More information on ETCP certification requirements can be found at etcp.esta.org or by contacting the SCC Director of Event Services.

Any rigging at SCC, either ground supported or aerial, must be installed by ETCP certified riggers. An ETCP certified rigger must be identified by the liable service provider as the Rigging Supervisor for all installations. This Rigging Supervisor must submit inspection and approval documents assuring that all rigging for each event, whether aerial or ground supported, is installed in a safe and effective manner, meeting all requirements, policies and procedures of SCC. This Rigging Supervisor must be on SCC's approved rigger list, and must submit a signed acknowledgement of compliance with SCC rigging rules and regulations.

Certified riggers may be employed by service contractors authorized by the event license holder or secured from labor organizations that are signatories to the SCC Labor Council Agreement. All service providers and labor organizations must submit their ETCP certified rigger documentation to the SCC Director of Operations at least one week prior to



Rigging Guidelines

working in the facility. This documentation will be accepted at the Security Entrance, by mail or email. SCC will maintain an approved list of names and certification expiration dates for all ETCP certified riggers at the Security Entrance. Once an individual has been accepted on the SCC's approved list of certified riggers, it is not necessary to re-submit documentation unless the certification expiration date passes. For the purpose of training apprentice riggers to accumulate the necessary hours required to apply for ETCP rigging certification, contractors may utilize one non-certified rigging technician per three ETCP certified riggers on the same call. ETCP certified riggers must review and certify all work performed during training.

Upon arrival at SCC for rigging duty, certified riggers must show identification and be on the approved ETCP rigger list. SCC Security will issue the rigger a specific wristband that allows performance of rigging installations within the facility. Any rigger who is not visibly wearing the appropriate wristband will be required to immediately stop working and will be asked to go to Security Control for verification. Repeat offenses of rigging without a visible wristband will be cause for permanent removal from the approved list.